

## **Printer Set up**

## To check the information

- Power on
- Hold down the POWER key for five seconds, then release
- INFORMATION shows
- Press the POWER key to scroll through the INFORMATION list

SPEED - NORMAL
DEEP - NORMAL
PAPER - LABEL
CMD - TSPL
SENSOR THROUGH
LANGUAGE - ENG
FACTORY

The above are the correct settings. To change the settings, press the **FEED** key until you see the correct detail and then press **POWER** to set.

If the labels keep feeding through, press and hold the **FEED** key until either a series of numbers appears (older model) or you can hear a "ding" (latest model) and this will reset the label feed.

**Please note**. Always keep the ceramic contacts free of debris/adhesive.